


☛ "Loctite 120"

☛ 7 / 8	☛ *	80 N.m
☛ 8 / 16	☛ *	100 N.m

*	
Sens de serrage	Kiristysyysuunta
Tightening direction	Atdragningsriktning
Sentido de apriete	Tilstrammingsretning
Anziehrichtung	Tilspændingsretning
Senso di serraggio	Schroefrichting
Sentido de aperto	Φορά σύσφιξης



Index No.	Part No.	Description	Q'ty
1	637.118	Pin	1
2	657.14	O-Ring	1
3	658.87	O-Ring	1
4	790.14	Needle	2
5	6153211940	Washer	1
6	6156811140	Valve Spring	1
7	6157460680	Adaptor 1/4 f	1
8	6153000450	Handle	1
9	6153100410	Trigger	1
10	6153211960	Valve	1
11	6153211970	Upper Seat	1
12	6153201400	Thickness Plate	1
13	6153211980	Lower Seat	1
14	6151430480	Piston	1
15	6152610600	Stop	1
16	6151010100	Barrel - Cylinder	1
17	6152520080	Tool Holder	1
18	6152520090	Tool Holder - BL	1
19	470173	Decal - Warning	1
20	6153210920	Button	1
21	6156371620	Collet - Sleeve	1
22	6153140540	Collet - Sleeve	1
23	6156811280	Spring	1
24	6153212160	Bolt	1
A	390.32	Handle Assembly (Include 1-3-6-7-8-9-10-20-21-22-23-24)	1

	470173	Warning Label
--	--------	---------------

Recommended Accessories
Air Tool Oil
CA149661 (4fl oz. - 120ml)
CA046000 (1pt.- 450ml)
P089507 (1 gal. - 3,8l)

Spare parts without part numbers are not sold separately - High wear parts are underlined.